

Hand Sanitizing Stand

ITEM NO.	PART NUMBER	QTY.
1	Base with Stud	1
2	Base with Offset	1
3	Bottom Tube	1
4	Top Tube	1
5	Topper	1

- Add base with stud to base with offset
- Screw bottom tube to base using screw on base
- Screw top tube to top with topper assembly using screw on the topper
- Snap top tube and bottom tube together with spring button

Sign Units Only – affix sign unit with magnet centered.
Sign drops in from top.

To affix a dispenser to any Astoria stand, use the adhesive pad the dispenser came with, or place the Twin Stick squares in the corners and across the top of your dispenser, depending on the model of dispenser. Affix to the dispenser first and then to the stand, leaving clearance for hand insertion.

Dual Unit Only – to affix a pump bottle (up to 1 quart) on the fork tab, loosen the cap slightly, slide onto the fork and retighten the cap.

Proudly
Made in USA

